

What type of systems can be surveyed?

Examples of what can be scanned:

- Electrical switch gear, breakers, bus connections, and contacts
- Mechanical couplings on rotating equipment
- Process piping and heat exchangers
- Motor and generator connections, windings, feeders and excitors
- Bearings
- Friction in drive gears and drive belts
- Refractory systems (e.g., boilers, kilns, molten material containment).

What type of findings are reported?

starting point. Reports can be tailored to meet specific needs. Specific information can be included in the report that can bring light to the severity of the situation. Reports typically include an image of the condition, both in infrared and visual light, an analysis as to why the condition exists, and suggestions for correcting (t)324 Td o4 Td o4 Td to 4 Td (e)-2 (the condition exists).

The photos of the electrical system condition are only the